




Firmware Upgrade D-Link DIR 825

Configuring Your Router

STEP 1 (a): Connect Your PC to the Router

- Unbox the router and power up the router.
- Connect the Act internet cable to the WAN/Internet port (different colored port) of the router.
- An extra cable will be available with the router, take LAN cable connect one end to the LAN port(1-4) Of the router (any one port) and one end to the PC or Laptop.
- In the system press  key & R key together  +  to open Run dialog box.
- Type ipconfig on the command prompt (Black screen). The default gateway of the LAN or Ethernet adapter will be the Router address. (Ex:192.168.1.1)

```
C:\Users\USER>ipconfig
Windows IP Configuration


Wireless LAN adapter Wireless Network Connection:

Media State . . . . . : Media disconnected
Connection-specific DNS Suffix . : ATRIA
```

STEP 1 (b): Connect Your Mobile

- Switch on the router and connect ACT internet cable to the WAN/Internet port of the router
- Go to setting in the Mobile, turn on Wi-Fi and wait until the mobile detects router name press The router name to connect.
- If the router is already configured and the Wi-Fi password is known then go to settings in the Mobile
- Under “Wireless and Networks”, press Wi-Fi make sure "Wi-Fi" is turned on.
- Wait until the mobile detects router name press the router name if prompted enter the Wi-Fi Password and press Connect.

STEP 2: Logging into the Router

- Open a browser  Enter the below IP Address in the Address Bar. A login page appears. The usual usernames and passwords are given in the table below.

Router Name	IP Address	Username	Password
Cisco or Linksys	192.168.1.1	admin	admin
D-Link	192.168.0.1	admin	(blank)
TP-Link	192.168.0.1	admin	admin
Net gear	192.168.1.1	admin	password
Belkin	192.168.2.1	Click on Login in Home	(blank)
Tenda	192.168.0.1	admin	admin
i-Ball Baton	192.168.1.1	admin	admin
Digisol	192.168.2.1	admin	1234 or admin
Asus	192.168.1.1	admin	admin

- If all the above credentials do not work, please check the back of the router where the Username and password will be mentioned.

STEP 2.1: Logging into the Router

The username is “Admin” and no password (blank)



2.5.39
DIR-825AC | **D-Link**[®]
English  Building Networks for People

DIR-825AC. Authorization required

Login


Password

STEP 3 (As and when required): Firmware upgrade

Under System > firmware upgrade > Select the update file from the PC which has been downloaded from the router website > Update the router




You can choose to download a Firmware version and then upload it offline or choose to download directly from internet itself



STEP 4: Saving Configuration

Save all the settings by going to System > Save

This Step is Mandatory. Not saving Configuration will lead to Loss of Configuration Changes done till now.



THANK YOU