




The logo for ACT, featuring the letters 'ACT' in a bold, red, sans-serif font with a white outline, positioned above a large, light pink circular arrow pointing to the left.

# Configuring a D-Link Router

DIR-615 Basic Configuration Steps

# Configuring Your Router

## STEP 1 (a): Connect Your PC to the Router

- Unbox the router and power up the router.
- Connect the Act internet cable to the WAN/Internet port(different coloured port) of the router.
- An extra cable will be available with the router, take LAN cable connect one end to the LAN port(1-4) of the router(any one port) and one end to the PC or Laptop.
- In the system press  key & R key together  +  to open Run dialog box.
- Type ipconfig on the command prompt(Black screen) . The default gateway of the LAN or Ethernet adapter will be the Router address. (Ex:192.168.1.1)

```
C:\Users\USER>ipconfig
Windows IP Configuration

Wireless LAN adapter Wireless Network Connection:

    Media State . . . . . : Media disconnected
    Connection-specific DNS Suffix . : ATRIA

Ethernet adapter Local Area Connection:

    Connection-specific DNS Suffix . :
    IPv4 Address. . . . . : 192.168.1.101
    Subnet Mask . . . . . : 255.255.255.0
    Default Gateway . . . . . : 192.168.1.1
```



## STEP 1 (b): Connect Your Mobile

- Switch on the router and connect ACT internet cable to the WAN/Internet port of the router
- Go to setting in the Mobile, turn on Wi-Fi and wait until the mobile detects router name press the router name to connect.
- If the router is already configured and the Wi-Fi password is known then go to settings in the Mobile
- Under “Wireless and Networks”, press Wi-Fi make sure "Wi-Fi" is turned on.
- Wait until the mobile detects router name press the router name if prompted enter the Wi-Fi password and press Connect.

## NOTE

- Every Router Configuration has two parts
  - Configuring the Internet Part, where we tell the Router how to connect to the internet.
  - Configuring the Wi-Fi Part, where we decide the name and password with which we connect to the Router
- Internet Configuration shown here will guide to Configure the Router in PPPoE.
  - This will enable you to browse internet directly, every time you connect to the router. No need to login again and again.
- Wi-Fi Configuration has also been given, in order to ease the process of you connecting to the Router
  - SSID and Password Creation have been explained

## STEP 2: Logging into the Router

- Open a browser → Enter the below IP Address in the Address Bar. A login page appears. The usual usernames and passwords are given in the table below.

Router Name	IP Address	Username	Password
Cisco or Linksys	192.168.1.1	admin	admin
D-Link	192.168.0.1	admin	(blank)
TP-Link	192.168.0.1	admin	admin
Netgear	192.168.1.1	admin	password
Belkin	192.168.2.1	Click on Login in Home	(blank)
Tenda	192.168.0.1	admin	admin
i-Ball Baton	192.168.1.1	admin	admin
Digisol	192.168.2.1	admin	1234 or admin
Asus	192.168.1.1	admin	admin

- If all the above credentials do not work, please check the back of the router where the username and password will be mentioned.



## STEP 2: Home Page After Logging Into the Router

Product Page: DIR-615 Hardware Version:T2 Firmware Version: 21.02 Logout

**D-Link**

**Status** | **Status** | **Network** | **Security** | **Advance** | **Management** | **Diag** | **Help**

| Device | WAN | LAN | Remote Management

Basic Device

**Basic Device Info**

Device Model	RG_CTC
Device ID	9CD643-E46F137C9795
Hardware Version	T2
Software Version	21.02

### STEP 3: Internet Connectivity – PPPoE Configuration



**D-Link**

**Network** | Status | **Network** | Security | Advance | Management | Diag | Help

WAN | LAN | Wi-Fi | Remote Management | QoS | Time | Routing

Internet Connection

**WAN Settings**

Uplink Mode: LAN  
Connection Name: 1\_INTERNET\_R\_VID\_  
Mode: Routing

IP Address  
 **PPPoE**

Select this if your ISP uses IP mode  
Select this if your ISP uses PPPoE

PPPoE Routing/Bridge  
MTU: 1492  
Select IP protocol: Ipv4  
Enable NAT:   
Enable VLAN:   
Vlan ID: 0  
802.1p: 0  
Service Mode: INTERNET

**3** ACT Username  
Password

User Name: username  
Password: \*\*\*\*\*  
Service Name:  
Dial-Up Mode: Auto connection  
Timeout: 0

Bound Port:  
 Port\_1  Port\_2  
 Port\_3  Port\_4  
 Wireless (ROOT/SSID1)  Wireless (SSID2)  
 Wireless (SSID3)  Wireless (SSID4)

Enable DHCP Server:

**4**

In network settings, choose PPPoE, enter ACT login ID and password and then click apply.

## STEP 4: Wi-Fi Connectivity – Router SSID/Password Configuration



The screenshot shows the D-Link router's configuration interface. The top navigation bar includes 'Network', 'Status', 'Network', 'Security', 'Advance', 'Management', 'Diag', and 'Help'. Under the 'Network' tab, 'WLAN' is selected. The left sidebar has 'Basic WLAN' and 'WLAN Security' options. The main content area is titled 'Wireless Settings - Basic' and contains various configuration options. A red box highlights the 'SSID' field with the value 'dir615t2'. A red arrow points from the 'Basic WLAN' link in the sidebar to the SSID field. Another red arrow points from the 'Save/Apply' button at the bottom of the settings to the text below.

**Basic WLAN**  
WLAN Security

**Wireless Settings - Basic**  
In this page, you can configure basic features of wireless LAN interface, including enabling or disabling wireless LAN interface and setting SSID.  
Click "Save/Apply" to take the basic wireless settings into effect.

Disable wireless

SSID: dir615t2

Enable:  Enable  Disable

Broadcast SSID:  Enable  Disable

Mode: 2.4 GHz (B+G+N)

Chanel Width: 40MHZ

Channel: Auto Current Channel: 2

Transmit Power (%): 100%

Beacon Interval: 100 (20-1024 ms)

Short Interval:  Enable  Disable

Data Rate: Auto

Connected Clients: Display Connected Clients

Save/Apply

Next go to WLAN security and choose the encryption mode and password, then click on apply

In network settings, choose WLAN settings and assign the SSID for the router. SSID is the Router Name you want to give.

The screenshot shows the D-Link router's configuration interface for 'Wireless Settings - Security'. The top navigation bar is the same as the previous screenshot. Under the 'Network' tab, 'WLAN' is selected, and 'WLAN Security' is chosen in the left sidebar. The main content area is titled 'Wireless Settings - Security' and contains security configuration options. A red box highlights the 'Encryption Mode' section, which includes 'WPA-PSK/WPA2-PSK', 'TKIP+AES', and 'WPA Pre-shared Key' fields. A red arrow points from the 'WLAN Security' link in the sidebar to the encryption mode section. Another red arrow points from the 'Apply' button at the bottom of the settings to the text below.

**Basic WLAN**  
**WLAN Security**

**Wireless Settings - Security**  
In this page, you can configure security features of the wireless LAN interface, including authentication mode, encryption mode, key for wireless network authentication and key length.

Encryption Mode: WPA-PSK/WPA2-PSK

Encryption Mode: TKIP+AES

WPA Pre-shared Key Format: Password

WPA Pre-shared Key: .....

Apply



## Changes to be Made After Configuration

- If the Wi-Fi password is changed, we need to update the password in all the devices to get connected to the Internet.
- Changes in PC
  - **Windows 7:** Click on Windows button → click on Control Panel → click on Network and Internet → click on Network and Sharing Centre.
  - In the Tasks pane(Left side of screen), click Manage wireless networks
  - Right-click the router name → click Remove network → click on OK.
  - Click on Network icon(right bottom corner next to system Time), click on Router name and enter the new Wi-Fi password and Connect.

- Changes in PC

- **Win 8,8.1:** Click on Network icon(right bottom corner next to system Time), Right click on Router name click on “Forget this network”. Again click on Router name, enter the new Wi-Fi password and Connect.
- **Win 10:** Click on Network icon(right bottom corner next to system Time), click on Network settings under Wi-Fi click on Manage known Networks → Click on your Router name and Click on Forget, and again click on Network icon → click on Router name enter the new Wi-Fi password and Connect

- Mobile or Tablet

- Go to ‘Settings’ in Mobile, turn on Wi-Fi and long press on your Router name and press “Forget network”. Again press the router name. You will be prompted to enter the Wi-Fi password . Enter the Password and Connect.